

## Viewing Statistics for Specific JUNOS Device Drivers (C-Web Interface)

**Purpose** View SNMP statistics about devices.

**Action** 1. Select **SAE** from the side pane, click **Statistics**, and then click **Device**.

The Device pane appears.

The screenshot shows the Juniper C-Web Interface. On the left is a navigation pane with a tree structure. The 'SAE' item is selected and highlighted in orange. The main content area is titled 'SAE' and 'Device'. It contains a form with two input fields: 'Device Name' (a text box) and 'Style' (a dropdown menu). Below these fields are 'OK' and 'Reset' buttons. To the right of the form, there is explanatory text: 'Name of a device. Please enter: All or part of the device name. For JUNOS router drivers and PCMM drivers, use the format default@routerName.' and 'Output style Choices: brief: Display only device names'. The top of the interface shows 'Monitor' in the title bar, 'Logged in as: admin', and links for 'About', 'Refresh', and 'Logout'. The bottom of the interface shows a copyright notice for Juniper Networks, Inc. and the 'Juniper Your Net.' logo.

Monitor	Logged in as: admin	About	Refresh	Logout
ACP	SAE			
CLI	Device			
Component				
Date				
Disk				
Interfaces...				
JPS				
NIC				
NTP				
Redirect Server				
Route...				
SAE				
Security				
System				

Device Name

Style

OK Reset

Name of a device.  
Please enter: All or part of the device name. For JUNOS router drivers and PCMM drivers, use the format default@routerName.

Output style  
Choices:  
brief: Display only device names

Copyright © 2007, Juniper Networks, Inc. All Rights Reserved. Trademark Notice. Privacy. Juniper Your Net.

2. In the Device Name box, enter a full or partial device name for which you want to display information, or leave the box blank to display all devices.
3. Select an output style from the Style list.
4. Click **OK**.

The Device pane displays statistics for all devices.

