

## Viewing Login Registrations

**Purpose** You can view all login registrations, or you can view a specific registration.

**Action** To view information about login registrations:

1. Click **Monitor > SAE > Registered > Login**.

The Registered/Login pane appears.

SAE Registered / Login	
Mac Address	<input type="text"/> <small>MAC address of login registrations. Value: MAC address in the format xx:xx:xx:xx:xx:xx Default: No value</small>
Maximum Results	<input type="text"/> <small>Number of results to be displayed. Legal range: 1..INF Default: 25</small>
Slot	<input type="text"/> <small>Display SAE information for a specified slot. Value: Currently the chassis has only one slot. The valid value is 0. Default: 0</small>
Style	<input type="text"/> <small>Output style Choices: brief: Display only MAC address of login registrations Default: Detail</small>

OK Reset

Copyright © 2007, Juniper Networks, Inc. All Rights Reserved. Trademark Notice. Privacy. Juniper Your Net.

2. In the MAC Address box, enter a MAC address that specifies the login registrations that you want to display.

Use the format:

**xx:xx:xx:xx:xx:xx**

3. In the Maximum Results box, enter the maximum number of results that you want to receive.
4. In the Slot box, enter the number of the slot for which you want to display login registration information.
5. Select an output style from the Style list.
6. Click **OK**.

The Registered/Login pane displays information about the login registrations.

**Related Topics** ■ For information about login and equipment registrations, see the *SRC-PE Sample Applications Guide*.

