

## Viewing SNMP Statistics About Policies

**Purpose** View SNMP statistics about policies.

**Action** Click **Monitor > SAE > Statistics > Policy Management**.

The Statistics/Policy Management pane appears.

The screenshot shows the Juniper Networks configuration interface. The top navigation bar includes 'Monitor', 'Configure', 'Diagnose', and 'Manage'. The 'Monitor' tab is selected, and the left sidebar shows a tree view with 'SAE' highlighted. The main content area is titled 'SAE Statistics / Policy Management'. It contains a 'Slot' input field with a value of '0'. To the right of the input field is a text box that reads: 'Display SAE information for a specified slot. Value: Currently the chassis has only one slot. The valid value is 0. Default: 0'. Below the input field are 'OK' and 'Reset' buttons. The bottom of the interface shows the copyright notice 'Copyright © 2007, Juniper Networks, Inc. All Rights Reserved. Trademark Notice. Privacy.' and the Juniper logo.

1. In the Slot box, enter the number of the slot for which you want to display SNMP statistics for policies.
2. Click **OK**.

The Statistics/Policy Management pane displays statistics for policies.

