

Viewing SNMP Statistics About RADIUS

Purpose View SNMP statistics about RADIUS.

Action 1. Click **Monitor > SAE > Statistics > RADIUS**.

The Statistics/RADIUS pane appears.

The screenshot shows the Juniper Networks configuration interface. The top navigation bar includes 'Monitor', 'Configure', 'Diagnose', and 'Manage'. The user is logged in as 'admin'. The left sidebar lists various configuration categories: ACP, CLI, Component, Date, Disk, Interfaces..., Iptables..., JPS, NIC, NTP, Redirect Server, Route..., SAE (highlighted), Security, and System. The main content area displays the 'SAE Statistics / RADIUS' pane. It features a 'Slot' input box with a value of '0'. A tooltip explains: 'Display SAE information for a specified slot. Value: Currently the chassis has only one slot. The valid value is 0. Default: 0'. Below the input box are 'OK' and 'Reset' buttons. The footer contains copyright information for Juniper Networks, Inc. (© 2007) and the slogan 'Juniper your Net.'

2. In the Slot box, enter the number of the slot for which you want to display SNMP statistics for RADIUS.
3. Click **OK**.

The Statistics/RADIUS pane displays statistics for RADIUS.

