

Viewing SNMP Information for RADIUS Clients with the CLI

Purpose View SNMP information for RADIUS clients. You can view information for all accounting or authentication clients, or by IP address, UDP port number, or IP address and UDP port.

Action To view SNMP information for RADIUS accounting clients:

```
user@host> show sae statistics radius client accounting
```

To view SNMP information for RADIUS authentication clients:

```
user@host> show sae statistics radius client authentication
```

To view information for a particular RADIUS client by IP address:

```
user@host> show sae statistics radius client ip-address ip-address
user@host> show sae statistics radius client accounting ip-address ip-address
user@host> show sae statistics radius client authentication ip-address ip-address
```

To view information for a particular RADIUS client by UDP port number:

```
user@host> show sae statistics radius client udp-port udp-port
user@host> show sae statistics radius client accounting udp-port udp-port
user@host> show sae statistics radius client authentication udp-port udp-port
```

To view only the RADIUS clients that were accessible by IP address and port number:

```
user@host> show sae statistics radius client brief
user@host> show sae statistics radius client accounting brief
user@host> show sae statistics radius client authentication brief
```

