

Operating the SNMP Agent

You must configure the SNMP agent and then manually start the agent. If you attempt to manually start the SNMP agent before it is configured, the software displays a message that the agent has not been configured and cannot start.

The SNMP agent automatically restarts in the event of a host reboot or process failure that stops the agent.

- Related Topics**
- Configuring the SNMP Agent
 - Configuration Statements for the SNMP Agent

