

Commands to Manage Simulated Subscribers

You can use the following operational mode commands to manage simulated subscribers.

- request sae login ipv4 authenticated-dhcp
- request sae login ipv4 authenticated-interface
- request sae login ipv4 unauthenticated-dhcp
- request sae login ipv4 unauthenticated-interface
- request sae logout dn
- request sae logout ip
- request sae logout login-name
- request sae logout session-id
- show sae subscribers
- show sae subscribers dn
- show sae subscribers ip
- show sae subscribers login-name
- show sae subscribers session-id

Related Topics

- Overview of Simulated Subscribers
- For detailed information about each command, see the *SRC-PE CLI Command Reference*
- Logging In Simulated Subscribers with the CLI
- Logging Out Simulated Subscribers with the CLI
- Viewing Subscriber Sessions

