

Removing an SRC Authentication Method from the Authentication Order

To delete the `radius` statement from the authentication order:

- Enter the following command:

```
[edit system]
user@host# delete authentication-order [(radius | tacplus)]
```

For example:

```
[edit system]
user@host# delete authentication-order radius
```

- Related Topics**
- Types of Authentication for SRC User Accounts
 - Configuring Authentication for SRC User Accounts
 - Example: Configuring SRC Authentication

