

## Starting the C-Web Interface

---

Before you start the C-Web interface, verify whether access is configured for HTTP or HTTPS.

To start the C-Web interface:

1. From a Web browser, enter the name or IP address of the SAE and the port number for the C-Web interface.

**https:// host :port/**

or

**http:// host :port/**

The C-Web interface login page appears.

2. On the login page, type your username and password, and click Log In.

The Monitor page appears.

- Related Topics**
- Accessing the C-Web Interface
  - Enabling the C-Web Interface
  - Logging Out of the C-Web Interface
  - C-Web Interface Overview

