

## Configuring the SLE

---

In Service Creation Manager, configure the following:

1. Create passive authentication configuration, and enable subscriber learning.
2. Create a switch configuration, and apply the passive authentication configuration to the switch configuration.
3. Create a switch that corresponds to your e30 Switch, and apply the switch configuration \*to the switch.

You also need to enable accounting in the SLE. To do so, log in to the SLE Configuration Console console, and check the AccountingEnabled service attribute in the AccountingService window.

- Related Topics**
- Provisioning the IPSCS
  - Integration of the SRC Software and the Ellacoya DPI Platform
  - Configuring a Virtual Router Object for DPI

