

Configuring JPS to Store Log Messages in a File

To configure logging destinations to store log messages in a file:

1. From configuration mode, access the configuration statement that configures the name and type of logging destination. In this sample procedure, the logging destination called log2 is configured.

```
user@host# edit slot 0 jps logger log2 file
```

2. Specify the properties for the logging destination.

```
[edit slot 0 jps logger log2 file]  
user@host# set ?
```

For more information about configuring properties for the logging destination, see Overview of Logging for SRC Components.

3. (Optional) Verify your configuration.

```
[edit slot 0 jps logger log2]  
user@host# show  
file {  
  filter !NoAckRksEvent,/info-;  
  filename var/log/jps_info.log;  
  rollover-filename var/log/jps_info.alt;  
  maximum-file-size 2000000000;  
}
```

- Related Topics**
- Overview of the JPS
 - Configuring the JPS
 - Configuring Logging Destinations for the JPS
 - Configuring JPS to Send Log Messages to System Logging Facility

