

Configuring Advanced NIC Features

If you want to configure NIC features not available at the basic editing level, set the editing level to advanced or expert and use the CLI Help to obtain information about statement options.

- Related Topics**
- Configuring the NIC (SRC CLI)
 - Configuring a NIC Scenario (SRC CLI)
 - Configuring NIC to Store Log Messages in a File (C-Web Interface)

