

Removing Equipment Registrations (C-Web Interface)

You can delete all equipment registrations, or you can delete a specific registration. The demonstration residential portal included with the SRC Application Library provides an example of how to use equipment registration.

To remove equipment registrations:

1. Click **Monitor > SAE > Registered > Equipment**.

The Equipment pane appears.

2. Enter information as described in the Help text in the main pane, and click **OK**.

To remove login registrations:

1. Click **Manage > Clear > SAE > Registered > Equipment**.

The Equipment pane appears.

2. Enter information as described in the Help text in the main pane, and click **OK**.

- Related Topics**
- Removing Equipment Registrations
 - Removing Login Registrations (C-Web Interface)
 - Viewing Equipment Registrations
 - Reloading the SAE Data (C-Web Interface)

