

Configuring Directory Monitoring Properties for the SDX SNMP Agent (C-Web Interface)

To configure properties for the SDX SNMP agent:

1. Click **Configure**, and expand **SNMP > Agent > Initial > Directory Eventing**.

The Directory Eventing pane appears.

2. Enter information as described in the Help text in the main pane, and then click **Apply**.

- Related Topics**
- Configuring Directory Monitoring Properties for the SDX SNMP Agent
 - Configuring Directory Connection Properties for the SDX SNMP Agent (C-Web Interface)
 - Configuring the SDX SNMP Agent (C-Web Interface)
 - Monitoring the SDX SNMP Agent (C-Web Interface)

