

## Upgrading SRC Software for a Component

---

To upgrade a specified SRC component:

- Specify the package name for a component when you enter the **request system upgrade** command.

```
user@host> request system upgrade url url package package
```

For example:

```
user@host> request system upgrade url ftp://myserver/SRC-PE-3.0.0R1  
package UMCnic
```

The C-series Controller automatically reboots at the end of the upgrade.

### Related Topics

- Overview of Software Management on a C-series Controller
- Before You Upgrade the Software on a C-series Controller
- Installing SRC Software for a Component
- Configuring SRC Components
- Configuring the SRC Software

