

Reloading Subscriptions

To reload all subscriptions from the directory:

```
user@host> request sae load subscriptions
```

Related service sessions are activated, deactivated, or reactivated as needed.

- Related Topics**
- Reloading the SAE Configuration
 - Viewing Statistics for Subscriber and Service Sessions with the CLI
 - For more information about viewing subscriber sessions with the SRC CLI, see Viewing General Information for Subscriber Sessions
 - Reloading the SAE Data

