

Monitoring the SDX SNMP Agent (C-Web Interface)

To display the SDX SNMP agent status:

1. Click **Monitor > Component**.

The system responds with a status message.

- Related Topics**
- Monitoring the SDX SNMP Agent
 - Configuring the SDX SNMP Agent (C-Web Interface)
 - Starting the SDX SNMP Agent (C-Web Interface)

