

Stopping the SDX SNMP Agent

To stop the SNMP agent:

```
user@host> disable component agent
```

The system responds with a stop message. If the SNMP agent is not running when you issue the command, the software responds with a warning message indicating that fact.

- Related Topics**
- Stopping the SDX SNMP Agent (C-Web Interface)
 - Starting the SDX SNMP Agent
 - Configuring the SDX SNMP Agent

