

Stopping the SDX SNMP Agent (C-Web Interface)

To stop the SNMP agent:

1. Click **Manage > Disable**.
2. From the Component box, select **agent**.

The system responds with a stop message. If the SNMP agent is not running when you issue the command, the software responds with a warning message indicating that fact.

- Related Topics**
- Stopping the SDX SNMP Agent
 - Starting the SDX SNMP Agent (C-Web Interface)
 - Configuring the SDX SNMP Agent (C-Web Interface)
 - Monitoring the SDX SNMP Agent (C-Web Interface)

