

Removing an Installed Component

To remove a component that is installed on a C-series Controller:

- Specify the package name for a component when you enter the `request system uninstall` command.

```
user @ host> request system uninstall package package
```

For example:

```
user @ host> request system uninstall package UMCnic
```

- Related Topics**
- Overview of Software Management on a C-series Controller
 - Installing SRC Software for a Component

