

Exporting a VTA Configuration to a Local File

To export a VTA configuration to a local file:

1. In the VTA Configuration Manager navigation pane, select **Export**.

The Export The Current Configuration page appears.



2. Right-click the word **here**, and then use your browser to save the file.

- Related Topics**
- Accessing the VTA Configuration
 - Loading and Importing VTA Configurations
 - Loading a Configuration from a Directory
 - Importing a VTA Configuration from a Local File
 - Committing a VTA Configuration to a Directory

