

## Viewing Edge Congestion Point Information by Subscriber Session

---

**Purpose** View edge congestion point information by subscriber session.

**Action** To display information about edge congestion points by subscriber session:

```
user@host> show acp edge congestion-point subscriber-session-id
```

To display information about specific congestion points by subscriber session:

```
user@host> show acp edge congestion-point subscriber-session-id session-id  
session-id
```

Enter a partial subscriber session ID to list all matching congestion points.

To display information about the congestion points from a specific virtual router:

```
user@host> show acp edge congestion-point subscriber-session-id  
virtual-router-name virtual-router-name
```

Enter a virtual router name to list congestion points from a particular virtual router.

To display congestion point DNs:

```
user@host> show acp edge congestion-point subscriber-session-id brief
```

By default, information about the congestion point attributes and congestion point bandwidth is displayed.

To restrict the number of displayed results:

```
user@host> show acp edge congestion-point subscriber-session-id maximum-results  
maximum-results
```

- Related Topics**
- Configuring SRC-ACP to Manage the Edge Network
  - Viewing Information About Edge Congestion Points by Subscriber Session (C-Web Interface)
  - Viewing Edge Congestion Point Information by DN

