

Viewing JPS CMTS Locator Statistics with the C-Web Interface

Purpose View information about the recent performance statistics for the CMTS locator.

Action Click **JPS > Statistics > CMTS Locator**.

The Statistics/CMTS Locator pane displays the CMTS locator statistics.

The screenshot displays the Juniper C-Web Interface. At the top, there is a navigation bar with tabs: Monitor (highlighted), Configure, Diagnose, and Manage. To the right of the tabs, it says "Logged in as: admin" and provides links for Refresh, Preferences, About, and Logout. On the left side, there is a vertical menu with expandable sections: CLI, Component, Date, Disk, Interfaces..., JPS (highlighted), NIC, NTP, Redirect Server, Route..., SAE, Security, and System. The main content area shows the "JPS" section expanded, with "Statistics / CMTS Locator" selected. Below this, a table displays the following statistics:

JPS CMTS Locator	
Number of lookups	0
Number of no-match lookups	0
Number of lookup errors	0
Minimum lookup time (ms)	0
Average lookup time (last 100 lookups, ms)	0
Maximum lookup time (ms)	0

At the bottom of the interface, a footer bar contains the copyright notice: "Copyright © 2007, Juniper Networks, Inc. All Rights Reserved. Trademark Notice. Privacy." and the Juniper logo with the tagline "Juniper your Net."

- Related Topics**
- Viewing JPS State
 - Specifying Connections to CMTS Devices (C-Web Interface)
 - Viewing JPS CMTS Statistics with the C-Web Interface
 - Viewing JPS CMTS Connections with the C-Web Interface
 - Overview of the JPS

