

Viewing JPS CMTS Statistics with the C-Web Interface

Purpose View information about recent performance statistics for the policy server-to-CMTS interface.

Action Click **JPS > Statistics > CMTS**.

The Statistics/CMTS pane displays statistics for the policy server-to-CMTS interface.

The screenshot displays the Juniper C-Web Interface. The top navigation bar includes 'Monitor', 'Configure', 'Diagnose', and 'Manage'. The user is logged in as 'admin'. The left sidebar shows a tree view with 'JPS' selected. The main content area is titled 'JPS CMTS Interface (PKT-MM-2)' and displays a table of statistics:

JPS CMTS Interface (PKT-MM-2)	
Connections opened	0
Connections closed	0
Sync-Request/SSQ broadcasts	0
Avg sync time (last 10 syncs, ms)	0
Timed out syncs	0

The footer of the interface shows the copyright notice: 'Copyright © 2007, Juniper Networks, Inc. All Rights Reserved. Trademark Notice. Privacy.' and the Juniper logo with the tagline 'Juniper your Net.'

- Related Topics**
- Viewing JPS State
 - Specifying Connections to CMTS Devices (C-Web Interface)
 - Viewing JPS CMTS Connections with the C-Web Interface
 - Viewing JPS CMTS Locator Statistics with the C-Web Interface
 - Overview of the JPS

