

Viewing Data for NIC Agents

Purpose	<p>To interpret the data for agents, make sure that you have a good understanding of the NIC resolution process.</p> <p>See Overview of the NIC Resolution Process.</p> <p>View all NIC resolver data.</p>
Action	<pre>user@host> show nic data agent</pre> <pre>Component name /agents/LoginNameVr Key Type Ip String 192.170.179.0 Value Type Vr String vorbis-13@prsim Key Type Ip String 192.170.179.3 Value Type Vr String vorbis-13@prsim ... Key Type Vr String default@sys1 Value Type SaeId String IOR: 000000000000003549444C3A736D67742E6A756E697065722E6E65742F7361652F53657276696365 41637469766174696F6E456E67696E653A312E300000000000000200000000000007800010200 0000000C31302E3232372E362E34330022610000000000226761726B6269742E6B616E6C61622E6A 6E70722E6E65742F736165504F412F5341450000000000200000000000008000000004A414300 000000010000001C0000000000010001000000010501000100010109000000010501000100000001 0000002C000000000000000001000000010000001C0000000000010001000000010501000100010109 0000000105010001</pre>
Meaning	<p>Table 1 on page 2 describes the output fields for the <code>show nic data agent</code> command. Output fields are listed in the order in which they appear.</p>

Table 1: Output Fields for show nic data agent

Field Name	Field Description
Component name	Name of an agent. Agent names have the format <code>/agents/ agent-name</code> .
Key	Data type and value of a NIC key. The value is the actual value of the NIC key, not the NIC value to which the key maps.
Value	Data type and value of the NIC value that maps to the associated NIC key.

- Related Topics**
- Viewing Statistics for NIC Agents
 - Viewing Agents
 - Viewing Agent Statistics
 - Viewing Data for NIC Resolvers