

Viewing Routing Table Information

Purpose You can display brief or detailed information about the route from the local system to a remote host.

Action To view brief route information:

user@host> **show route**

Kernel IP routing table									
Destination	Gateway	Genmask	Flags	MSS	Window	irrtt	Iface		
192.2.2.0	' ' ' ' ' ' '*		255.255.255.0	U		0 0		0	eth0
default	src1ab1.mylab.	0.0.0.0	UG	0 0		0	eth0		

To view detailed route information:

user@host> **show route detail**

Kernel IP routing table											
Destination	Gateway	Genmask	Flags	Metric	Ref	Use	Iface	MSS	Window	irrtt	
192.2.2.0	' ' ' ' ' ' '*		255.255.255.0	U	0	0		0	eth0	' ' ' ' '0	0
0											
default	src1ab1.mylab.	0.0.0.0	UG	0	0	0	eth0	' ' ' ' '0	0	0	

The detailed output includes the additional Metric, Ref, and Use fields.

- Related Topics**
- Viewing Information About the Routing Table (C-Web Interface)
 - Viewing the Route Information
 - Viewing Interface Information
 - Testing Connectivity to Remote Hosts
 - Overview of Commands to Troubleshoot Connections to Remote Hosts

