

Viewing Statistics for Specific JUNOS Device Drivers (SRC CLI)

Purpose Display statistics for a specific JUNOS device driver.

Action Use the following operational mode command:

```
show sae statistics device <name name> < (brief) >
```

For example:

```
user@host> show sae statistics device name default@jrouter
SNMP Statistics
Add notification handle time      7
Change notification handle time   0
Client ID                        default@troll
Delete notification handle time   0
Failover IP                      0.0.0.0
Failover port                    0
Handle message time               40
Job queue age                    0
Job queue time                    0
Number message send               3
Number of added jobs              0
Number of add notifications       0
Number of change notifications    0
Number of delete notifications    0
Number of managed interfaces      3
Number of message errors          0
Number of message timeouts        0
Number of removed jobs            0
Number of user session established 0
Number of user session removed    0
Router type                      JUNOS
Up time                          7036120
Using failover server             false
```

- Related Topics**
- Viewing Statistics for Specific JUNOS Device Drivers (C-Web Interface)
 - Viewing the State of JUNOS Device Drivers (SRC CLI)
 - Viewing Statistics for All JUNOS Device Drivers (SRC CLI)

