

Viewing Information About Policies

Purpose View information about the policies available on the SAE.

Action 1. Click **Monitor > SAE > Policies**.

The Policies pane appears.

Field	Description	Value	Legal range	Default
Policy Group	Name of a policy group.		All or part of the policy group name	No value
Maximum Results	Number of results to be displayed.	25	1..INF	25
Slot	Display SAE information for a specified slot.	0	Currently the chassis has only one slot. The valid value is 0.	0
Style	Output style.	brief	Choices: brief: Display only policy group names	detail

- In the Policy Group box, enter a full or partial policy name for which you want to display information, or leave the box blank to display all policies.
- In the Maximum Results box, enter the maximum number of results that you want to receive.
- In the Slot box, enter the number of the slot for which you want to display policy information.
- Select an output style from the Style list.
- Click **OK**.

The Policies pane displays the status of the policies configured on the SAE.

- Related Topics**
- Configuring Access to Policy Data
 - Viewing SNMP Information for Policies with the CLI
 - Viewing SNMP Statistics About Policies

