

Viewing SNMP Statistics for Directory Connections

Purpose View SNMP statistics for directory connections.

Action 1. Click **Monitor > SAE > Statistics > Directory > Connections**.

The Statistics/Directory/Connections pane appears.

2. In the Connection ID box, enter a full or partial connection ID for which you want to display information, or leave the box blank to display all SNMP statistics for all directory connections.
3. In the Slot box, enter the number of the slot for which you want to display SNMP statistics for directory connections.
4. Select an output style from the Style list.
5. Click **OK**.

The Statistics/Connections pane displays statistics for directory connections.

- Related Topics**
- [Configuring SAE Properties for Global Default SNMP Communities for Use with JUNOS Routers and JUNOS Routing Platforms](#)
 - [Viewing Statistics for Directory Connections with the CLI](#)
 - [Viewing Statistics About the Directory with the CLI](#)
 - [Viewing SNMP Statistics for the Directory](#)

