

Viewing SNMP Statistics About Server Processes

Purpose View SNMP statistics about server processes.

Action 1. Click **Monitor > SAE > Statistics > Process**.

The Statistics/Process pane appears.

The screenshot shows the Juniper SAE web interface. The top navigation bar includes 'Monitor', 'Configure', 'Diagnose', and 'Manage'. The user is logged in as 'admin'. The left sidebar lists various components: ACP, CLI, Component, Date, Disk, Interfaces..., Iptables..., JPS, NIC, NTP, Redirect Server, Route..., SAE (highlighted), Security, and System. The main content area is titled 'SAE Statistics / Process'. It features a 'Slot' input box with a value of '0'. A tooltip explains: 'Display SAE information for a specified slot. Value: Currently the chassis has only one slot. The valid value is 0. Default: 0'. Below the input box are 'OK' and 'Reset' buttons. The bottom of the interface shows the copyright notice 'Copyright © 2007, Juniper Networks, Inc. All Rights Reserved. Trademark Notice. Privacy.' and the Juniper logo.

2. In the Slot box, enter the number of the slot for which you want to display SNMP statistics for server processes.
3. Click **OK**.

The Statistics/Process pane displays statistics for server processes.

- Related Topics**
- Configuring SAE Properties for Global Default SNMP Communities for Use with JUNOS Routers and JUNOS Routing Platforms
 - Viewing SNMP Information for the SAE Server Process with the CLI

