

Viewing Statistics for Dynamic Service Activator (SRC CLI)

Purpose View general statistics for Dynamic Service Activator with the SRC CLI.

Action user@host> `show dsa statistics general`

- Related Topics**
- Overview of Dynamic Service Activator
 - Starting Dynamic Service Activator (SRC CLI)

