

## Configuration Statements for Component Logging

---

Use the following configuration statements to configure logging for SRC components. You access these statements from the hierarchy for a component, such as:

- [edit shared acp configuration]
- [edit shared sae configuration]
- [edit shared nic scenario *scenario-name* ]
- [edit snmp agent]
- [edit slot 0 jps]

```
logger name {  
  file-logger {  
    filter filter ;  
    filename filename ;  
    rollover-filename rollover-filename ;  
    maximum-file-size maximum-file-size ;  
  }  
  syslog-logger {  
    filter filter ;  
    syslog-host syslog-host ;  
    syslog-facility syslog-facility ;  
    format format ;  
  }  
}
```

- Related Topics**
- For detailed information about each configuration statement, see *SRC-PE CLI Command Reference*.
  - Configuring System Logging (SRC CLI)
  - Configuring a Component to Store Log Messages in a File (SRC CLI)
  - Before You Configure Logging
  - Overview of Logging for SRC Components

