

Configuring NIC to Store Log Messages in a File (C-Web Interface)

To configure component logging for NIC:

1. Click **Configure**, expand **Shared**, and then click **NIC**.

The NIC pane appears.

2. In the side pane, expand a configuration scenario, such as Scenario:OnePopSharedlp.
3. In the side pane, expand a host, such as Demohost.

The Hosts pane appears.

4. From the Create new list, select **Logger**.

The name of the logger appears in the side pane and the Logger pane.

5. Expand the logger in the side pane, and then click **File** or **Syslog**.
6. Click **Create**, enter information as described in the Help text in the main pane, and click **Apply**.

- Related Topics**
- Configuring a Component to Store Log Messages in a File (SRC CLI)
 - Configuring ACP to Store Log Messages in a File (C-Web Interface)
 - Configuring the SAE to Store Log Messages in a File (C-Web Interface)
 - Configuring the SNMP to Store Log Messages in a File (C-Web Interface)
 - Configuring JPS to Store Log Messages in a File (C-Web Interface)

