

## Specifying Maximum Number of RADIUS Peers with the SRC CLI

---

The dynamic RADIUS server can maintain a certain number of peers.

To specify the maximum number of peers with the SRC CLI:

1. From configuration mode, access the SAE configuration statement that configures dynamic RADIUS options.

```
[edit]  
user@host# edit shared sae configuration dynamic-radius-server
```

2. Specify the maximum number of peers maintained by the dynamic RADIUS server.

```
[edit shared sae configuration dynamic-radius-server]  
user@host# set maximum-cached-peer maximum-cached-peer
```

- Related Topics**
- Configuring Packet-Mirroring Support in an SRC Network
  - Defining RADIUS Attributes for Dynamic Authorization Requests with the SAE Core API
  - Example: Using the Sample Packet-Mirroring Application
  - Overview of Packet Mirroring Services

