

Enabling Expansion of JUNOSe Classify-Traffic Conditions (SRC CLI)

For information about expanded classifiers, see Policy Information Model.

Use the following configuration statement to enable or disable the expansion of JUNOSe classifiers.

```
shared sae configuration policy-management-configuration {  
    enable-junos-classifier-expansion;  
}
```

To enable or disable the expansion of JUNOSe classifiers:

1. From configuration mode, access the configuration statement that configures policy management properties on the SAE.

```
user@host# edit shared sae configuration policy-management-configuration
```

2. Specify whether or not the SAE expands the JUNOSe classify-traffic conditions into multiple classifiers before it installs the policy on the router.

```
[edit shared sae configuration policy-management-configuration]  
user@host# set enable-junos-classifier-expansion
```

- Related Topics**
- Before You Configure Classify-Traffic Conditions
 - Configuring Classify-Traffic Conditions
 - Specifying Port Access for Traffic Classification (SRC CLI)
 - Creating a Classify-Traffic Condition (SRC CLI)
 - Enabling Expansion of JUNOSe Classify-Traffic Conditions (C-Web Interface)

