

Removing the Directory Blacklist

To remove the directory blacklist:

1. Issue the `show sae directory-blacklist` command to view information about the directory blacklist.
2. Issue the `clear sae directory-blacklist` command to remove the directory blacklist.

- Related Topics**
- Removing the Directory Blacklist (C-Web Interface)
 - Removing Login Registrations
 - Viewing Information About the Directory Blacklist with the CLI
 - Commands to Manage SAE Data
 - Reloading the SAE Data

