

## Configuring the CoA Script Service with the SRC CLI

---

To configure the script service, you provide parameter substitutions with the values that are in the service definitions.

To configure parameters:

1. From configuration mode, enter the service parameter configuration. In this sample procedure, the service called CoAservice is configured in the global service scope.

```
user@host# edit services global service CoAservice parameter
```

2. (Optional) Configure actual values for other parameters.

```
[edit services global service CoAservice parameter]  
user@host# set substitution [ substitution... ]
```

The script file */SDK/scriptServices/coa/ldif/BOD1M.ldif* in the **SDK+AppSupport+Demos+Samples.tar.gz** file provides parameters specified by the sample CoA script service. You can use the sample script service as a starting point. See Parameters for Sample CoA Script Service.

- Related Topics**
- Overview of CoA Script Service
  - Configuring Subscriptions to the CoA Script Service
  - Creating the CoA Script Service with the SRC CLI
  - Configuring CoA Script Services
  - Example: Using the Sample CoA Script Service

