

Configuring the SAE to Use TLS

To configure the SAE to accept TLS connections, enter a port number with the **set beep-server-port** command in the JUNOS router driver configuration.

See [Configuring the SAE to Manage JUNOS Routing Platforms](#) .

Related Topics

- [Configuring the SAE to Use TLS](#)
- [Configuring TLS on the SAE](#)
- [Configuring JUNOS Routing Platforms to Interact with the SAE](#)
- [Monitoring Interactions Between the SAE and JUNOS Routing Platforms](#)

