

Configuring the SAE to Use TLS

To configure the SAE to accept TLS connections:

1. Click **Configure**, expand **Shared > Network**, and then click a JUNOS router.

The Device pane appears.

2. Type a port number in the Beep Server Port box, and click **Apply**.

- Related Topics**
- Configuring the SAE to Manage JUNOS Routing Platforms (C-Web Interface)
 - Configuring TLS on the SAE
 - Configuring JUNOS Routing Platforms to Interact with the SAE
 - Monitoring Interactions Between the SAE and JUNOS Routing Platforms

