

Adding Virtual Routers Individually

To add a virtual router to an existing router:

1. Click **Configure**, expand **Shared > Network**, and then click a JUNOS router.

The Device pane appears.

2. From the Create new list, select **Virtual Router**.
3. Type a name for the new device in the dialog box, and click **OK**.

The Virtual Router pane appears.

4. Enter information as described in the Help text in the main pane, and click **Apply**.

- Related Topics**
- For information about service scopes, see [Configuring Service Scopes \(SRC CLI\)](#)
 - [Overview of Adding JUNOS Routing Platforms and Virtual Routers](#)
 - [Adding the Server Certificate on the Routing Platform](#)
 - [Adding the Client Certificate on the Router](#)
 - [Adding Operative JUNOS Routing Platforms](#)
 - [Adding JUNOS Routers Individually](#)

