

## Removing a Certificate Request

---

To remove a certificate request:

1. Review the certificate request files on the system. These files are in the `/tmp` directory and have the file extension `.csr`.
2. Issue the `clear security certificate-request` command to remove a file. For example:

```
user@host> clear security certificate-request certreq.csr
```

- Related Topics**
- Manually Obtaining Digital Certificates
  - Obtaining Digital Certificates through SCEP

