

Enabling the Service Configuration on the SRC CLI

Before you can configure services with the SRC CLI, you must enable the policy, service, and subscriber editor on the SRC CLI. To do so:

In operational mode, enter the following command:

```
user@host> enable component editor
```

- Related Topics**
- Overview of Services for the SRC Software
 - Enabling the Service Configuration on the C-Web Interface
 - Before You Configure SRC Services
 - Adding a Normal Service (SRC CLI)
 - Setting Parameter Values for Services (SRC CLI)

