

Importing a VTA Configuration from a Local File

If your VTA configuration is stored in a local file, you need to import the file into VTA Configuration Manager. To do so:

1. In the VTA Configuration Manager navigation pane, select **Import**.

The Import Configuration page appears.

The screenshot shows the Juniper VTA Configuration Manager interface. The top header includes the Juniper Networks logo and the title 'VTA Configuration Manager' with a sub-tab 'Import Configuration'. On the left, a navigation pane lists options: Home, Dir Connection, Configuration (expanded), Create, Edit, Load, Commit, Import (highlighted), and Export. The main content area is titled 'Import:' and instructs the user to 'Please choose a property file from the local file system.' It features a form with a 'From file:' label, a text input field, a 'Browse...' button, and 'Finish' and 'Cancel' buttons. The bottom of the page displays the 'Juniper yourNet' logo.

2. Enter the filename and path in the From file field, or click **Browse** and select a file from the local host.
3. Click **Finish**.

- Related Topics**
- Loading a Configuration from a Directory
 - Loading and Importing VTA Configurations
 - Committing a VTA Configuration to a Directory
 - Specifying How the SRC-VTA Loads Configurations from the Directory
 - Accessing the VTA Configuration

