

Viewing Backbone Congestion Point Information by DN

Purpose View backbone congestion point information by DN.

Action To display information about backbone congestion points by DN:

```
user@host> show acp backbone congestion-point dn
```

To display information about specific congestion points by DN:

```
user@host> show acp backbone congestion-point dn congestion-point-dn  
congestion-point-dn
```

Enter a partial congestion point DN to list all matching congestion points.

To display information about the congestion points from a specific virtual router:

```
user@host> show acp backbone congestion-point dn virtual-router-name  
virtual-router-name
```

Enter a virtual router name to list congestion points from a particular virtual router.

To display congestion point DNs:

```
user@host> show acp backbone congestion-point dn brief
```

By default, information about the congestion point attributes and congestion point bandwidth usage is displayed.

- Related Topics**
- Configuring SRC-ACP to Manage the Backbone Network
 - Viewing Information About Congestion Points in a Backbone Network by DN (C-Web Interface)
 - Viewing Backbone Congestion Point Information by Service

