

Viewing SNMP Information for SRC-ACP

Purpose View SNMP information for SRC-ACP.

Action To display statistics for SRC-ACP SNMP information:

```
user@host> show acp statistics general
```

- Related Topics**
- Viewing SNMP Information for Devices
 - Viewing SNMP Information for the Directory

