

Viewing Information About Components Installed (C-Web Interface)

Purpose View the installed SRC components.

Action Click **Monitor > Component**.

The Component pane displays the status of each installed component.

The screenshot shows the Juniper C-Web Interface. The top navigation bar includes 'Monitor', 'Configure', 'Diagnose', and 'Manage'. The 'Monitor' tab is selected, and the 'Component' sub-tab is active. The left sidebar lists various system components like ACP, CLI, Date, Disk, Interfaces..., Iptables..., JPS, NIC, NTP, Redirect Server, Route..., SAE, Security, and System. The main content area, titled 'Component', displays a table of installed components. The table has three columns: Name, Version, and Status. The components listed are cli (running), acp (stopped), editor (running), jdb (running), redir (disabled), nic (stopped), sae (stopped), www (disabled), jps (disabled), agent (stopped), and webadm (running). The footer of the interface shows the copyright notice for Juniper Networks, Inc. and the slogan 'Juniper Your Net.'.

Name	Version	Status
cli	Release: 1.1 Build: hstewart_SDX_7.1.0_unix-200707	running
acp	Release: 7.1 Build: hstewart_SDX_7.1.0_unix-200708	stopped
editor	Release: 7.1 Build: hstewart_SDX_7.1.0_unix-200708	running
jdb	Release: 7.0 Build: DIRXA.A.MAIN.1123	running
redir	Release: 7.0 Build: REDIR.A.MAIN.1136	disabled
nic	Release: 7.1 Build: hstewart_SDX_7.1.0_unix-200708	stopped
sae	Release: 7.1 Build: hstewart_SDX_7.1.0_unix-200708	stopped
www	Release: 7.0 Build: UMC.A.MAIN.1093	disabled
jps	Release: 7.1 Build: hstewart_SDX_7.1.0_unix-200708	disabled
agent	Release: 7.1 Build: hstewart_SDX_7.1.0_unix-200708	stopped
webadm	Release: 7.1 Build: hstewart_SDX_7.1.0_unix-200708	running

- Related Topics**
- Viewing Information About Components Installed (SRC CLI)
 - Viewing C-series Controller Information
 - Directories on the C-series Controller

