

## Monitoring Interactions Between the SAE and the JUNOSe Router

---

**Purpose** Monitor connection between the SAE and a JUNOSe router.

**Action** To monitor the connection between the router and the SAE:

- Use the `show sscd info` command on the JUNOSe router

To display the version number of the SRC client:

- Use the `show sscd version` command on the JUNOSe router.

See the *JUNOSe Command Reference Guide* for details about these commands.

You can also monitor the interactions between the SRC software and the router in the log files for the SAE and in the log files generated by the JUNOSe router.

- For information about configuring logging on JUNOSe routers, see *JUNOSe System Event Logging Reference Guide*.

- Related Topics**
- Specifying Router Initialization Scripts on the SAE with the CLI
  - Configuring the SAE to Manage JUNOSe Routers with the CLI
  - Troubleshooting Problems with Managing JUNOSe Routers

