

Viewing Server Process Information for the Diameter Server (SRC CLI)

Purpose View information about the server process.

Action Purpose View information about the server process. Action To display about the server process:

```
user@host > show diameter statistics process
```

