

Viewing SNMP Statistics About RADIUS

Purpose View SNMP statistics about RADIUS.

Action 1. Click **Monitor > SAE > Statistics > RADIUS**.

The Statistics/RADIUS pane appears.

The screenshot shows the Juniper Networks configuration interface. The top navigation bar includes 'Monitor', 'Configure', 'Diagnose', and 'Manage'. The user is logged in as 'admin'. The left sidebar lists various components: ACP, CLI, Component, Date, Disk, Interfaces..., Iptables..., JPS, NIC, NTP, Redirect Server, Route..., SAE (highlighted), Security, and System. The main content area is titled 'SAE Statistics / RADIUS'. It contains a 'Slot' input field with a dropdown arrow, a text box with the value '0', and a 'Display SAE information for a specified slot.' label. Below the input field are 'OK' and 'Reset' buttons. A tooltip is visible over the '0' value, stating: 'Value: Currently the chassis has only one slot. The valid value is 0. Default: 0'. The footer of the interface shows the copyright notice 'Copyright © 2007, Juniper Networks, Inc. All Rights Reserved. Trademark Notice. Privacy.' and the Juniper logo.

2. In the Slot box, enter the number of the slot for which you want to display SNMP statistics for RADIUS.
3. Click **OK**.

The Statistics/RADIUS pane displays statistics for RADIUS.

- Related Topics**
- Configuring SAE Properties for Global Default SNMP Communities for Use with JUNOS Routers and JUNOS Routing Platforms
 - Viewing SNMP Statistics About RADIUS Clients

