

## Monitoring Statistics for External Subscriber Monitor Event Notifications

---

**Purpose** Display real-time statistics about event notifications for External Subscriber Monitor.

**Action** To display real-time statistics about event notifications for External Subscriber Monitor:

```
user@host> monitor external-subscriber-monitor event-notifications
```

To specify the time for refreshing the data:

```
user@host> monitor external-subscriber-monitor event-notifications interval  
interval
```

**Related Topics** ■ Viewing Statistics for External Subscriber Monitor Event Notifications

